

KETTLER

Palma Cube

0193336-2100/5510



IMPORTANT

PLEASE KEEP THIS BOOKLET FOR FUTURE REFERENCE.
THIS IS IMPORTANT INFORMATION REGARDING THE USE AND
CARE OF YOUR GARDEN FURNITURE.

Maintenance and Care Instructions



No assembly required for this product

- This product may only be used for its intended purpose for residential premises.
- Kettler furniture is designed to be left outdoor all year round (excluding cushions).
- Moving parts such as locking mechanisms, catches and joints need to be lubricated where necessary.
- We recommend you clean your Kettler furniture at the beginning and end of the season. To clean your Kettler furniture, use warm soapy water only. Never use abrasive chemicals or cleaning agents. Tree sap and bird droppings should be cleaned off immediately.
- Kettler cushions are not suitable for dry cleaning and are not machine washable. Sponge clean only.
- Kettler furniture can be covered - we recommend that you only use Kettler tailored covers.
- This product is 100% recyclable. At the end of the products life, please dispose of responsibly.
- Colours may vary slightly.



Attention

Please be aware that painted/varnished surfaces can be damaged by sunscreens. If the surface of your Kettler leisure furniture comes into contact with sunscreens, the surface is to be cleaned without delay as described above. Only in this way can lasting discolouration of the surface by the ingredients of the sunscreen be prevented.

Spare Parts

Please find below a general list of spare parts for this product.

Product Code	Description
SPGFS-PSC1	Palma Footstool Cushion
SPGCC-PSC1	Palma Footstool Cushion Cover
SPGTO-STOOL	Palma Footstool Elasticated Toggle
SPGTT-0193336R	Palma Cube Table Top Rattan
SPGTT-0193336W	Palma Cube Table Top Whitewash
SPGSL-0193336	Palma Cube Dark Oak Polywod Slat Straight
SPGSL-0193336C	Palma Cube Dark Oak Polywod Slat Corner
SPGFT-STOOL	Adjustable Footcap - Stool
SPGFT-TABLE	Adjustable Footcap - Palma Table

For help or assistance please call our customer services department on **01527 591901**.



Alternatively you can visit our website: www.kettler.co.uk/spares



Warranty For Home Use

This product is covered by a 3 year warranty against manufacturing faults. This warranty applies to domestic use only. It does not cover commercial use, mis-use or accidental damage.

To make a warranty claim, contact us with a valid proof of purchase and photos of the furniture.

Kettler (GB) Limited
Merse Road, North Moons Moat, Redditch, B98 9HL
Tel: 01527 591901 | Email: sales@kettler.co.uk

For Your Safety

- This product may only be used for its intended purpose as furniture for residential properties.
- Check all components regularly for correct function, damage and loose connections especially at the start of the season and at 1-2 month intervals dependent on use.
- Damaged components may endanger your safety or shorten the life of the product. Replace all damaged parts immediately. Use only spare parts manufactured by Kettler. Should you wish to purchase spare parts, they can be ordered directly from: www.kettler.co.uk/spares
- Kettler will not be responsible for damaged caused by improper use.



Attention

- Whilst assembling this product keep out of the reach of children. (Choking hazard – contains small parts)
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around.
- Always dispose of packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!
- We reserve the right to make changes for technical reasons.

KETTLER

Kettler GB Limited

Merse Road, North Moons Moat, Redditch, Worcestershire, B98 9HL

Tel: 01527 591901 Fax: 01527 62423

Email: sales@kettler.co.uk



www.kettler.co.uk

A member of the HEINZ KETTLER group of companies